



A PC-Based Development Programmer for the PIC16C84

Author: Robert Spur
Analog Design Specialist, Inc.

INTRODUCTION

This application note describes the construction of a low cost serial programmer which uses a PC with a parallel (Centronix printer) port to control a PIC16C84. This programmer has the capability of programming a PIC16C84 microcontroller, and reading back internal data without removing the device from the target circuit.

This feature is very useful in applications where changes in program code or program constants are necessary to compensate for other system features. For example, an embedded control system may have to compensate for variances in a mechanical actuator's performance or loading. The basic program can be programmed and tested during design phase. The final program and control constants can be easily added later in the production phase without removing the microcontroller from the circuit.

Automatic software and performance upgrades can also be implemented in-system. Upon receiving new system software via disk or modem, a control processor with the included programming code could perform in-circuit reprogramming of other microcontrollers in the system.

This programmer can load program code, part configuration, and EEPROM data into the PIC16C84. In read back mode, it can verify all data entries.

PROGRAMMING DESCRIPTION

The PIC16C84 microcontroller is placed into programming mode by forcing a low logic level on RB7 (pin 13) and RB6 (pin 12) while \overline{MCLR} (pin 4) is first brought low to reset the part, and then brought to the program/verify voltage of 12 to 14V. The \overline{MCLR} pin remains at the program/verify voltage for the remainder of the programming or verification.

After entering programming mode, RB7 is used to serially enter programming modes and data into the part. A high to low transition on RB6, the clock input, qualifies each bit of the data applied on RB7. Please refer to the PIC16C84 Programming Specification (DS30189) for details on the figures. The serial command-data format is specified in Figure 1.2.1.3 of the Microchip PIC16C84 Programming Specification (DS30189). The first 6 bits form the command field, and the last 16 bits form the data field. Notice that the data field is composed of one zero starting bit, 14 actual data bits, and one zero stop bit. The increment address command, shown in Figure 1.2.1.5 (PIC16C84 Programming Specification, DS30189), is comprised of only the command field. Table 1.2.1.1 (see DS30189) summarizes the available commands and command codes for serial programming mode.

Read mode is similar to programming mode with the exception that the data direction of RB7 is reversed after receiving the 6-bit command to allow the requested data to be returned to the programmer. Figure 1.2.1.4 (see DS30189) shows this sequence which starts by shifting the 6-bit command into the part. After the read command is issued, the programmer tri-states its buffer to allow the part to serially shift its internal data back to the programmer. The rising edge of RB6, (the clock input), controls the data flow by sequentially shifting previously programmed or data bits from the part. The programmer qualifies this data on the falling edge of RB6. Notice that 16 clock cycles are necessary to shift out 14 data bits.

Accidental in-circuit reprogramming is prevented during normal operation by the \overline{MCLR} voltage which should never exceed the maximum circuit supply voltage of 6 VDC and the logic levels of port bits RB7 and RB6.

After program/verification the \overline{MCLR} pin is brought low to reset the target microcontroller and then electrically released. The target circuit is then free to activate the \overline{MCLR} signal. In the event \overline{MCLR} is not forced by the target circuit, R4 (a 2 k Ω pull-up resistor in the programmer) provides a high logic level on the target microcontroller which enables execution of its program independent of the programmer connection. Provisions should be made to prevent the target circuit from resetting the target microcontroller with \overline{MCLR} or affecting the RB7 and RB6 pins during the programming process. In most cases this can be done without jumpers.

SOFTWARE DESCRIPTION

The listed code provides a hardware-software interface to a standard PC parallel (Centronix) interface port. The code can be adapted to a microprocessor parallel interface port by substituting an output command for the "biosprint" command.

Control software can transfer the PIC16C84 program, configuration bits, and EEPROM data from a standard PROM interface file into the target system by reading the file and calling the function in Example 1 using the appropriate command name in the definition table, and the data to be programmed. The command names are repeated here for reference.

LOAD_CONFIG	Sets PIC16C84 data pointer to configuration.
LOAD_DATA	Loads, but does not program, data.
READ_DATA	Reads data at current pointer location.
INC_ADDR	Increments PIC16C84 data pointer.

BEGIN_PROG	Programs data at current data pointer location.
PARALLEL_MODE	Puts PIC16C84 into parallel mode (not used).
LOAD_DATA_DM	Loads EEPROM data.
READ_DATA_DM	Reads EEPROM data.

Function "int ser_pic16c84(<command>,<data [or 0]>)" is called to perform command. Function returns internal data after read commands.

Do not forget to initiate the programming mode before programming, increment the addresses after each byte is programmed, and put the programmer in run mode after programming.

Designed by: Analog Design Specialist, Inc.
P.O. Box 26-0846
Littleton, CO 80126

EXAMPLE 1: PUT TARGET SYSTEM INTO PROGRAM MODE

```
.. program code..
ser_pic16c84(PROGRAM_MODE,0);
.. program code..
```

EXAMPLE 2: READ DATA FROM THE TARGET SYSTEM

```
.. program code..
data = ser_pic16c84(READ_DATA,0); // read data
// transfers data from target part to variable "data"
.. more program code..
```

EXAMPLE 3: PROGRAM DATA INTO THE TARGET SYSTEM

```
.. program code..
ser_pic16c84(LOAD_DATA,data); // load data into target
ser_pic16c84(BEGIN_PROG,0); // program loaded data
ser_pic16c84(INC_ADDR,0); // increment to next address
// transfers data from program variable "data" to target part
.. more program code..
```

EXAMPLE 4: PUT TARGET SYSTEM INTO RUN MODE

```
.. program code..
ser_pic16c84(RUN,0);
.. program code..
```

AN589

```

//***** FIGURE #2 *****
//**
//** SERIAL PROGRAMMING ROUTINE FOR THE PIC16C84 MICROCONTROLLER **
//**
//** Analog Design Specialists **
//**
//*****
//FUNCTION PROTOTYPE: int ser_pic16c84(int cmd, int data)

// cmd: LOAD_CONFIG -> part configuration bits
// LOAD_DATA -> program data, write
// READ_DATA -> program data, read
// INC_ADDR -> increment to the next address (routine does not auto increment)
// BEGIN_PROG -> program a previously loaded program code or data
// LOAD_DATA_DM -> load EEPROM data registers (BEGIN_PROG must follow)
// READ_DATA_DM -> read EEPROM data
//
// data: 1) 14 bits of program data or
// 2) 8 bits of EEPROM data (least significant 8 bits of int)

// Additional programmer commands (not part of PIC16C84 programming codes)
//
// cmd: RESET -> provides 1 ms reset pulse to target system
// PROGRAM_MODE -> initializes PIC16C84 for programming
// RUN -> disconnects programmer from target system
//
// function returns:1) 14 or 8 bits read back data for read commands
// 2) zero for write data commands
// 3) PIC_PROG_EROR = -1 for programming function errors
// 4) PROGMR_ERROR = -2 for programmer function errors

#include <bios.h>

#define LOAD_CONFIG 0
#define LOAD_DATA 2
#define READ_DATA 4
#define INC_ADDR 6
#define BEGIN_PROG 8
#define PARALLEL_MODE 10 // not used
#define LOAD_DATA_DM 3
#define READ_DATA_DM 5
#define MAX_PIC_CMD 63 // division between pic16c84 and programmer commands

#define RESET 64 // external reset command, not needed for programming
#define PROGRAM_MODE 65 // initialize program mode
#define RUN 66 // electrically disconnect programmer

#define PIC_PROG_EROR -1
#define PROGMR_ERROR -2

#define PTR 0 // use device #0

// parallel port bits
// d0: data output to part to be programmed
// d1: programming clock
// d2: data dirrection, 0= enable tri state buf -> send data to part
// d3: Vpp control 1= turn on Vpp
// d4: ~MCLR =0, 1 = reset device with MCLR line
// d5: clock line tri state control, 0 = enable clock line

int ser_pic16c84(int cmd, int data) // custom interface for pic16c84
{
    int i, s_cmd;

```

```

if(cmd <=MAX_PIC_CMD) // all programming modes
{
  biosprint(0,8,PTR); // set bits 001000, output mode, clock & data low
  s_cmd = cmd; // retain command "cmd"
  for (i=0;i<6;i++) // output 6 bits of command
  {
    biosprint(0,(s_cmd&0x1) +2+8,PTR); // set bits 001010, clock hi
    biosprint(0,(s_cmd&0x1) +8,PTR); // set bits 001000, clock low
    s_cmd >>=1;
  }

  if((cmd ==INC_ADDR) || (cmd ==PARALLEL_MODE) // command only, no data cycle
    return 0;

  else if(cmd ==BEGIN_PROG) // program command only, no data cycle
  {
    delay(10); // 10 ms PIC programming time
    return 0;
  }

  else if((cmd ==LOAD_DATA) || (cmd ==LOAD_DATA_DM) || (cmd ==LOAD_CONFIG)) // output 14 bits
  for (i=200;i;i-); // delay between command & data
  biosprint(0,2+8,PTR); // set bits 001010, clock hi; leading bit
  biosprint(0, 8,PTR); // set bits 001000, clock low

  for (i=0;i<14;i++) // 14 data bits, lsb first
  {
    biosprint(0,(data&0x1) +2+8,PTR); // set bits 001010, clock hi
    biosprint(0,(data&0x1) +8,PTR); // set bits 001000, clock low
    data >>=1;
  }
  biosprint(0,2+8,PTR); // set bits 001010, clock hi; trailing bit

  // ***** Analog Design Specialists *****

  biosprint(0, 8,PTR); // set bits 001000, clock low

  return 0;
}

else if((cmd ==READ_DATA) || (cmd ==READ_DATA_DM)) //read 14 bits from part, lsb first
{
  biosprint(0, 4+8,PTR); // set bits 001100, clock low, tri state data buffer
  for (i=200;i;i-); // delay between command & data
  biosprint(0,2+4+8,PTR); // set bits 001110, clock hi, leading bit
  biosprint(0, 4+8,PTR); // set bits 001100, clock low

  data =0;
  for (i=0;i<14;i++) // input 14 bits of data, lsb first
  {
    data >>=1; // shift data for next input bit
    biosprint(0,2+4+8,PTR); // set bits 001110, clock hi
    biosprint(0, 4+8,PTR); // set bits 001100, clock low
    if(!(biosprint(2,0,0)&0x40)) data += 0x2000; //use printer acknowledge line for input,
    //data lsb first
  }
  biosprint(0,2+4+8,PTR); // set bits 001110, clock hi, trailing bit
  biosprint(0, 4+8,PTR); // set bits 001100, clock low
  return data;
}

else return PIC_PROG_EROR; // programmer error
}
else if(cmd == RESET) // reset device

```

AN589

```
{
  biosprint(0,32+16+4,PTR);           // set bits 110100, MCLR = low
(reset                                // PIC16C84), programmer not connected
  delay(1);                            // 1ms delay
  biosprint(0,32 +4,PTR);             // set bits 100100, MCLR = high
  return 0;
}

else if(cmd ==PROGRAM_MODE)           // enter program mode
{
  biosprint(0,32+16+4,PTR);           // set bits 110100, Vpp off, MCLR =low
                                      //(reset PIC16C84)
  delay(10);                          //10 ms, allow programming voltage to stabilize

  biosprint(0,8,PTR);                 // set bits 001000, Vpp on , MCLR = 13.5 volts,
                                      // clock & data connected
  delay(10);                          // 10 ms, allow programming voltage to stabilize

  return 0;
}

else if(cmd ==RUN)                    // disconnects programmer from device
{
  biosprint(0,32+4,PTR);              // set bits 100100
  return 0;
}
else return PROGMR_ERROR;             // command error
}
```

WORLDWIDE SALES & SERVICE

AMERICAS

Corporate Office

Microchip Technology Inc.
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 602-786-7200 Fax: 602-786-7277
Technical Support: 602 786-7627
Web: <http://www.microchip.com>

Atlanta

Microchip Technology Inc.
500 Sugar Mill Road, Suite 200B
Atlanta, GA 30350
Tel: 770-640-0034 Fax: 770-640-0307

Boston

Microchip Technology Inc.
5 Mount Royal Avenue
Marlborough, MA 01752
Tel: 508-480-9990 Fax: 508-480-8575

Chicago

Microchip Technology Inc.
333 Pierce Road, Suite 180
Itasca, IL 60143
Tel: 630-285-0071 Fax: 630-285-0075

Dallas

Microchip Technology Inc.
14651 Dallas Parkway, Suite 816
Dallas, TX 75240-8809
Tel: 972-991-7177 Fax: 972-991-8588

Dayton

Microchip Technology Inc.
Two Prestige Place, Suite 150
Miamisburg, OH 45342
Tel: 937-291-1654 Fax: 937-291-9175

Los Angeles

Microchip Technology Inc.
18201 Von Karman, Suite 1090
Irvine, CA 92612
Tel: 714-263-1888 Fax: 714-263-1338

New York

Microchip Technology Inc.
150 Motor Parkway, Suite 416
Hauppauge, NY 11788
Tel: 516-273-5305 Fax: 516-273-5335

San Jose

Microchip Technology Inc.
2107 North First Street, Suite 590
San Jose, CA 95131
Tel: 408-436-7950 Fax: 408-436-7955

Toronto

Microchip Technology Inc.
5925 Airport Road, Suite 200
Mississauga, Ontario L4V 1W1, Canada
Tel: 905-405-6279 Fax: 905-405-6253

ASIA/PACIFIC

Hong Kong

Microchip Asia Pacific
RM 3801B, Tower Two
Metroplaza
223 Hing Fong Road
Kwai Fong, N.T., Hong Kong
Tel: 852-2-401-1200 Fax: 852-2-401-3431

India

Microchip Technology India
No. 6, Legacy, Convent Road
Bangalore 560 025, India
Tel: 91-80-229-0061 Fax: 91-80-229-0062

Korea

Microchip Technology Korea
168-1, Youngbo Bldg. 3 Floor
Samsung-Dong, Kangnam-Ku
Seoul, Korea
Tel: 82-2-554-7200 Fax: 82-2-558-5934

Shanghai

Microchip Technology
RM 406 Shanghai Golden Bridge Bldg.
2077 Yan'an Road West, Hongjiao District
Shanghai, PRC 200335
Tel: 86-21-6275-5700
Fax: 86 21-6275-5060

Singapore

Microchip Technology Taiwan
Singapore Branch
200 Middle Road
#10-03 Prime Centre
Singapore 188980
Tel: 65-334-8870 Fax: 65-334-8850

Taiwan, R.O.C

Microchip Technology Taiwan
10F-1C 207
Tung Hua North Road
Taipei, Taiwan, ROC
Tel: 886 2-717-7175 Fax: 886-2-545-0139

EUROPE

United Kingdom

Arizona Microchip Technology Ltd.
Unit 6, The Courtyard
Meadow Bank, Furlong Road
Bourne End, Buckinghamshire SL8 5AJ
Tel: 44-1628-851077 Fax: 44-1628-850259

France

Arizona Microchip Technology SARL
Zone Industrielle de la Bonde
2 Rue du Buisson aux Fraises
91300 Massy, France
Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany

Arizona Microchip Technology GmbH
Gustav-Heinemann-Ring 125
D-81739 München, Germany
Tel: 49-89-627-144 0 Fax: 49-89-627-144-44

Italy

Arizona Microchip Technology SRL
Centro Direzionale Colleone
Palazzo Taurus 1 V. Le Colleoni 1
20041 Agrate Brianza
Milan, Italy
Tel: 39-39-6899939 Fax: 39-39-6899883

JAPAN

Microchip Technology Intl. Inc.
Benex S-1 6F
3-18-20, Shin Yokohama
Kohoku-Ku, Yokohama
Kanagawa 222 Japan
Tel: 81-4-5471- 6166 Fax: 81-4-5471-6122

5/8/97



MICROCHIP

All rights reserved. © 1997, Microchip Technology Incorporated, USA. 6/97

Information contained in this publication regarding device applications and the like is intended for suggestion only and may be superseded by updates. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights. The Microchip logo and name are registered trademarks of Microchip Technology Inc. in the U.S.A. and other countries. All rights reserved. All other trademarks mentioned herein are the property of their respective companies.